



FIG. 2



00509735-062300

FIG. 4



002290" SE/66560

FIG. 6
FUNCTION INFORMATION ¹²⁶


ID	01		601
NAME	FUNCTION 01		602
POINTER	0x0000f000		603
SIZE	0x00000100		604
EXECUTION LEVEL	PRIORITY 1		605
VERSION	1.006		606
NEXT POINTER	HEAD OF FUNCTION 00		607
ACCESS AREA LIST INFORMATION	POINTER	0x0000 1000	608
	SIZE	0x0000 0010	609
	NUMBER	n	610

FIG. 7
ACCESS AREA LIST ¹²⁴

ACCESS AREA 0	HEAD	0x0000 0500	701
	SIZE	0x0000 0200	702
	ATTRIBUTE	r — —	703
ACCESS AREA 1	HEAD	0x0000 0300	701
	SIZE	0x0000 0051	702
	ATTRIBUTE	r w —	703
⋮	⋮	⋮	
ACCESS AREA n-1	HEAD	0x0000 1100	701
	SIZE	0x0000 0020	702
	ATTRIBUTE	r w x	703


00599735-06300

FIG. 8
FUNCTION SEND PROCEDURE



0059735 062300


FIG. 12 FUNCTION SERVER



0059735 062300


FIG. 13

FUNCTION
MANAGER




002290" SE 26560

FIG. 14 FUNCTION EXECUTION



005973-062000


FIG. 15



0599735 06200


FIG. 16

FUNCTION SERVER




00509735-06300

FIG. 18



0059935 062300

FIG. 19



003290" 52/66560

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
CRAFTSMAN		


FIG. 20

¹²⁶ FUNCTION INFORMATION

ID	01		601
NAME	FUNCTION 01		602
POINTER	0x0000f000		603
SIZE	0x00000100		604
EXECUTION LEVEL	PRIORITY 1		605
VERSION	1.006		606
ROLL BACK FLAG	ROLL BACK ON		2001
NEXT POINTER	HEAD OF FUNCTION 00		607
ACCESS AREA LIST INFORMATION	POINTER	0x0000 1000	608
	SIZE	0x0000 0010	609
	NUMBER	n	610


00599735-062300

FIG. 21 FUNCTION EXECUTION



00569735-062300

FIG. 24



00599735-062300

FIG. 26





FIG. 27



002290" 5E/66560

APPROVED	C.G. FIG.	
BY	CLASS	SUBCLASS
CRAFTSMAN		

FIG. 28




FIG. 29

